

2灯Lumine / 4灯Lumine / Hyper Mini SR-4 DMX Protocol

6ch Mode (全機種 共通)

Ch 1	Dimmer	0(0%)		255(100%)
Ch 2	Red	0(0%)		255(100%)
Ch 3	Green	0(0%)		255(100%)
Ch 4	Blue	0(0%)		255(100%)
Ch 5	White	0(0%)		255(100%)
Ch 6	Strobe	0(0%)	Open	14(4%)
		15(5%)	Slow Strobe Fast 	123(47%)
		124(48%)	Open	131(51%)
		132(52%)	Slow Random Strobe Fast 	252(98%)
		253(99%)	Open	255(100%)

その他のChannel Mode

2灯/4灯Lumine									4灯Lumine		
4ch			5ch-A			5ch-B			16ch		
Ch 1	ALL	Red	Ch 1	ALL	Red	Ch 1	ALL	Dimmer	Ch 1	LED1	Red
Ch 2		Green	Ch 2		Green	Ch 2		Red	Ch 2		Green
Ch 3		Blue	Ch 3		Blue	Ch 3		Green	Ch 3		Blue
Ch 4		White	Ch 4		White	Ch 4		Blue	Ch 4		White
			Ch 5		Strobe	Ch 5		White	Ch 5	Red	Ch 6
							Ch 7	Blue	Ch 7	Blue	
							Ch 8	White	Ch 8	White	
									Ch 15	LED4	Blue
								Ch 16	White		

4灯Lumine					Hyper Mini SR-4						
18ch			24ch		12ch			24ch			
Ch 1	Master	Dimmer	Ch 1	LED1	Dimmer	Ch 1	LED1	Red	Ch 1	LED1	Dimmer
Ch 2	LED1	Red	Ch 2		Red	Ch 2		Green	Ch 2		Red
Ch 3		Green	Ch 3		Green	Ch 3		Blue	Ch 3		Green
Ch 4		Blue	Ch 4		Blue	Ch 4		Red	Ch 4		Blue
Ch 5		White	Ch 5		White	Ch 5		Green	Ch 5		White
Ch 6	LED2	Red	Ch 6	Strobe	Ch 6	Blue	Ch 6	Strobe	Ch 6	LED2	Strobe
Ch 7		Green	Ch 7	Dimmer	Ch 7	Red	Ch 7	Dimmer			
Ch 8		Blue	Ch 8	Red	Ch 8	Green	Ch 8	Red			
Ch 17	LED4	White	Ch 23	LED4	White	Ch 11	LED4	Green	Ch 23	LED4	White
Ch 18	Master	Strobe	Ch 24		Strobe	Ch 12		Blue	Ch 24		Strobe